



[www.theypod.net](http://www.theypod.net)

877-932-7686

[solutions@yearoundinnovations.com](mailto:solutions@yearoundinnovations.com)

## Dispensing and Cutting Instructions

Once the Ypod is loaded with polyfilm, visqueen or other roll sheet materials, the Ypod is ready for use. The following are basic instructions for dispensing and cutting polyfilm roll material.



**1. Ypod loaded and ready for use.**



**2. Hook measuring tape at discharge slot, and dispense roll material to desired length.**



**3. Using a utility knife, cut the dispensed material along the cutting guide.**



**4. Material will be cut clean through the multiple layers with a straight, neat edge.**

\* Should the Ypod be used in wet environments, see the [Ypod Drilling Drainage Holes Instructions](#) page.